

Type Report

Report Date: 11/12/2015

0000000101 Surgard MLR2

Type No	Description	Action Plan
1	Printer Error	System Alarm
2	Printer Restored	Restoral, No Alarm
3	12V Battery Low	System Alarm
4	12V Battery Restored	Restoral, No Alarm
5	COM#1 Absent	System Alarm
6	COM#1 Restored	Restoral, No Alarm
7	UPS Low Battery	System Alarm
8	UPS Low Battery Restored	Restoral, No Alarm
10	Faulty Data Received on Line card	System Alarm
11	9V Battery Low	System Alarm
12	9V Battery Restored	Restoral, No Alarm
13	COM#2 Absent	System Alarm
14	COM#2 Restored	Restoral, No Alarm
15	AC Failure	System Alarm
16	AC Restored	Restoral, No Alarm
17	UPS AC Fail	System Alarm
18	UPS AC restored	Restoral, No Alarm
19	CPM2 Master Fail	System Alarm
20	Telephone Line Fault on line card	System Alarm
21	AC Failure	System Alarm
22	AC Restored	Restoral, No Alarm
23	UPS Low Batt.	System Alarm
24	UPS Low Batt. Restr.	Restoral, No Alarm
25	CPM2 Master Fail	System Alarm
30	Telephone Line Restored on Line card	Restoral, No Alarm
32	Telephone Line Fault On Line Card	System Alarm
40	Faulty Call; no Data Received	System Alarm
48	Telephone Line Restored On Line Card	Restoral, No Alarm
64	Faulty Call; No data recieved on Line C	System Alarm
177	Audio on line 1	System Alarm
178	Audio on line 2	System Alarm
179	Audio on line 3	System Alarm
180	Audio on line 4	System Alarm
181	Audio on line 5	System Alarm

182	Audio on line 6	System Alarm
183	Audio on line 7	System Alarm
184	Audio on line 8	System Alarm
185	Audio on line 9	System Alarm
186	Audio on line 10	System Alarm
187	Audio on line 11	System Alarm
188	Audio on line 12	System Alarm
189	Audio on line 13	System Alarm
190	Audio on line 14	System Alarm
193	Internal Communication Error	System Alarm
194	Internal Communication Error	System Alarm
195	Internal Communication Error	System Alarm
196	Internal Communication Error	System Alarm
197	Internal Communication Error	System Alarm
198	Internal Communication Error	System Alarm
199	Internal Communication Error	System Alarm
200	Internal Communication Error	System Alarm
201	Internal Communication Error	System Alarm
202	Internal Communication Error	System Alarm
203	Internal Communication Error	System Alarm
204	Internal Communication Error	System Alarm
205	Internal Communication Error	System Alarm
206	Internal Communication Error	System Alarm
208	CPM2 Reset	System Alarm
209	Line Card 01 Reset	System Alarm
210	Line Card 02 Reset	System Alarm
211	Line Card 03 Reset	System Alarm
212	Line Card 04 Reset	System Alarm
213	Line Card 05 Reset	System Alarm
214	Line Card 06 Reset	System Alarm
215	Line Card 07 Reset	System Alarm
216	Line Card 08 Reset	System Alarm
217	Line Card 09 Reset	System Alarm
218	Line Card 10 Reset	System Alarm
219	Line Card 11 Reset	System Alarm
220	Line Card 12 Reset	System Alarm
221	Line Card 13 Reset	System Alarm
222	Line Card 14 Reset	System Alarm
225	Line Card 01 Restored	Restoral, No Alarm
226	Line Card 02 Restored	Restoral, No Alarm
227	Line Card 03 Restored	Restoral, No Alarm
228	Line Card 04 Restored	Restoral, No Alarm
229	Line Card 05 Restored	Restoral, No Alarm
230	Line Card 06 Restored	Restoral, No Alarm
231	Line Card 07 Restored	Restoral, No Alarm
232	Line Card 08 Restored	Restoral, No Alarm
233	Line Card 09 Restored	Restoral, No Alarm

234	Line Card 10 Restored	Restoral, No Alarm
235	Line Card 11 Restored	Restoral, No Alarm
236	Line Card 12 Restored	Restoral, No Alarm
237	Line Card 13 Restored	Restoral, No Alarm
238	Line Card 14 Restored	Restoral, No Alarm
241	Line Card 01 Absent	System Alarm
242	Line Card 02 Absent	System Alarm
243	Line Card 03 Absent	System Alarm
244	Line Card 04 Absent	System Alarm
245	Line Card 05 Absent	System Alarm
246	Line Card 06 Absent	System Alarm
247	Line Card 07 Absent	System Alarm
248	Line Card 08 Absent	System Alarm
249	Line Card 09 Absent	System Alarm
250	Line Card 10 Absent	System Alarm
251	Line Card 11 Absent	System Alarm
252	Line Card 12 Absent	System Alarm
253	Line Card 13 Absent	System Alarm
254	Line Card 14 Absent	System Alarm
65000	Receiver in error has Restored	Restoral, No Alarm
65001	Client Late to close	System Alert
65002	No signals received from client	System Alarm
65003	Receiver Failure	System Alarm
65005	Manual Paging Signal	Zone Info, No Alarm
65006	Pager/Email Failure	System Alarm
65007	Client Unset out of hours	System Alert
65009	IRFast descript logged without details	System Alarm
65012	Caller ID logged	Zone Info, No Alarm
65020	Polling Restore	Restoral, No Alarm
65021	Polling Failure	System Alarm
65022	IRFast No description logged	System Alarm
65023		Zone Info, No Alarm
65024		Zone Info, No Alarm
65025		Zone Info, No Alarm
65026	Change of Logs	Zone Info, No Alarm
65027	Successful Send	Zone Info, No Alarm
65028	Alarm no restoral received	System Alarm
65029	Bad checksum in signal	System Alarm
65030	Comm port error	System Alarm
65031	Bad caller ID	System Alarm
65032	Bad unrecognised data	System Alarm
65046	Start of listen in	Zone Info, No Alarm
65047	End of listen in	Zone Info, No Alarm
65050	Multi-knock	Zone Info, No Alarm

65051	Late to open	System Alert
65052	Early to close	System Alert
65053	Email error	System Alarm
65054	Poll signal	Zone Info, No Alarm
65055	Receiver error message	System Alarm
65056	Attend Report	Zone Info, No Alarm
65057	Publishing Failed	System Alarm
65058	Publishing Restored	Restoral, No Alarm
65059	Attend Report Complete	Zone Info, No Alarm
65061	Task dropped off network	System Alarm
65062	Task restored	Restoral, No Alarm
65063	Slave dropped off network	System Alarm
65064	Slave restored	Restoral, No Alarm
65065	Archive of current log was successful	Zone Info, No Alarm
65066	Archive of current log has failed	System Alarm
65067	Archive clean was successful	Zone Info, No Alarm
65068	Archive clean has failed	System Alarm
65069	WWW Archive was successful	Zone Info, No Alarm
65070	WWW Archive has failed	System Alarm
65071	Automatic Data Backup was successful	Zone Info, No Alarm
65072	Automatic Data Backup has failed	System Alarm